

DDSP logbook

Initial 'toy' system

I have implemented a modular system in pytorch, with the following:

1. **FIRFilter1D**:

- Implements an arbitrary phase FIR filter using a 1D convolutional layer.
- The filter taps are learnable parameters.

2. **FIRFilter1DLinearPhaseI**:

- Implements a linear phase FIR type I filter using 1D convolution.
- Only allows an odd number of taps and enforces type I symmetry in the filter taps.
- Taps are learnable parameters (only from the mid-index and up).

3. **GammaToneFilter**:

- Impulse response of the filter is computed based on specified parameters like center frequency, sampling frequency, and impairment factor
 - !Impairing like this makes no sense just something I did for the toy example.
- The filter is applied to the input signal using a 1D convolutional layer.

4. **GammaToneFilterbank**:

- Uses the **GammaToneFilter** module to create individual filters and applies them to the input signal as a filterbank.

5. **NormalModel**:

- Uses a **GammaToneFilterBank** to process the input with no pre-gain (FIR filter).

6. **ImpairedModel**:

- Uses a **FIRFilter1D** to apply a learnable gain filter to process which then gets processed by **GammaToneFilterBank**.
- The gain filter is implemented using **FIRFilter1D**, I have not tried using **FIRFilter1DLinearPhaseI**, although it should work with no issues.

7. **MyModel_v1**:

- A trainable model composed of a normal hearing model and an impaired hearing model.
- Uses the **NormalModel** and **ImpairedModel** to process the input and produce outputs for normal and impaired hearing, respectively.


I have tried training a **NormalModel** using SGD with the SI-SDR loss between normal and impaired outputs as the loss function, which was successful. The results are presented under RESULTS below.

Next steps


- ☐ Try to mimic how the DHASP paper implemented the differentiable perceptual model.
- ☐ Try to mimic how the DHASP paper implemented the differentiable hearing-aid processing model.
- ☐ Introduce a perceptual loss to optimize the NN.

RESULTS



Normal Hearing filterbank used:



Impaired filterbank used:



Input-output of untrained model



input

▶

0:00 / 0:01

🔊

normal out (target)

▶ 0:00 / 0:01

🔊

untrained impaired out

▶ 0:00 / 0:01



🔊

trained impaired out


▶ 0:00 / 0:01

🔊

Input-output of trained model



Learned filter



unnormalized frequency

